
Overview

WARNINGS

- This product must be installed in accordance with all applicable codes by a person familiar with the product.
- Each luminaire must be properly supported during install.
- **DO NOT** join fixtures on the floor prior to lifting, or damage will occur.
- **Before beginning installation**, review our complete list of warnings by visiting www.saylite.com/warnings.





We believe in the power of light.



1 of 6

Preparation - Tools/Parts Identification

A. Identify Fixtures

Texas Fluorescents Reinvented


Saylite **LED**

PART# 44PSQXXLRXXWXXXXLDMVXXKWH


VOLTAGE: 120-277, 50/60HZ WATTAGE: XX MAX FLUX: XXXX LUMENS


DATE CODE: XX/XX/XX

TYPE: XX



B. Tools Needed






Safety Glasses

- Use labels found on the box and inside fixture bodies to identify bodies.
 NOTE: Locations of labels can vary.


- Remove all fixtures from their boxes.
 Organize fixtures based on their labels at the install location.

- Always use proper safety equipment when installing fixtures.
 Tools shown are recommended for standard install. Tools needed
- may vary based on actual install location conditions.

C. Identify Parts



5" White Canopy - Non Power PN: CBGCAN51W



5" White Canopy - Power PN: CBGCAN52W



44 SQUARE HANGING KIT FOUR PER FIXTURE

- Read entire install instructions before beginning installation.
 Unpack all components and arrange in order of install steps.
 For help with installation, please contact us at www.saylite.com or call us at (972) 247-3171.


Step 1 - Prepare Ceiling


A. Install Ceiling Bracing



B. Install Mounting Bar








- NOTE: Ceiling bracing installed in this step must be able to support fixture weight of 100lbs.
- Securely install J-Box in desired location, flush with the outside face of ceiling panel.
- Securely install 2 ceiling studs on either side of the J-Box at 6" between inside faces.
- Securely install 2 pieces of Unistrut upon the ceiling studs at a 6" between inside faces.


- NOTE: Confirm bracing installed in previous step is able to support fixture weight of 100lbs.
- Install the mounting bar to the J-Box using 2 #8-32 screws as shown.



Step 2 - Install Ceiling Cables

A. Install Ceiling Cables





- Once the shipping crate is opened, locate the hanging kit and remove all steel cables.
- Feed C-3/32 cable in to the oblong as shown by rotating the paddle as parallel to the cable as possible (see detail "A").
- Repeat for the remaining cables. The fixture is now ready to be secured to the ceiling bracing.




DETAIL B INSTALLED

Step 3 - Install Fixture


A. Install Fixture Cables

Saylite

Texas Fluorescents Reinvented








-PASS CABLE AROUND UNISTRUT, SECURE TO OPPOSITE SIDE

- Pass C-3/32 cable thru the non-power feed pendant canopy in the direction and orientation shown.
- Repeat for all remaining cables.

- Pass the C-3/32 cable thru one side of the C-3/32 Loop Gripper, around the preinstalled Unistrut and back in to the opposite side of the Loop Gripper as shown. Repeat for all remaining cables.
- · Adjust cables to desired length at this time.




5" White Canopy - Non Power




Saylite

Texas Fluorescents Reinvented

A. Secure The Canopy




- Run the power cable up the desired fixture pendant cable to the power feed canopy.
- Secure the power cable to the pendant cables using zip ties.
- Secure the power cable to the power feed canopy using the cable strain relief.



WIRING LEGEND		
Black	Hot	Line Voltage
White	Neutral	Line Voltage
Green	Ground	
Gray	Dimming	0-10V DC
Violet	Dimming	0-10V DC

- Make final adjustments of cables, ensuring fixture is level.
- Wire the fixture to the incoming supply according to all local, state and national codes.
- Fixture install is now complete.

B. Level/Wire The Fixture



5" White Canopy - Power

