

Commercial Retrofit Kit Installation Instructions

STEP 1

Turn off Power.

STEP 2

Remove existing reflector and disconnect whip from junction box.

STEP 3

Attach Vantage light engine power lead to power of existing junction box.

STEP 4

Insert light engine through existing hole in ceiling

STEP 5

Attach Vantage clips to existing frame, use the clips shaped like an L on horizontal frames with the long legs on the pan or the clips shaped like a U on a vertical flange with the long sides on the inside of the flange.

STEP 6

Attach reflector with screws through the key slots in the reflector to the light engine housing.

STEP 7

Install reflector up into frame.

STEP 8

Energize.

COMMERCIAL RETROFIT KIT CONTENTS

